

The Spiral inductor (**ref. 065000**) is designed to heat large thicknesses, and is recommended for straightening, shrink heating and shrinking (metal constructions). The Spiral inductor produces a round heating cavity. The inductor cover (**ref. 069701**) is easy to remove, allowing the distance between the coil and the workpiece to be heated to be maintained. The cover can be removed to heat aluminium or copper.

Mandatory software version: V6.52

## INDUCTORS IN ACTION



Straightening

Copper 15 mm

Heating ring

## RECOMMENDED USES

### Optimum use


Straightening;  
 Chaude de retrait;  
 Mass heating;  
 HGV garage.

### Possible use


Pre-heating;  
 Heating on aluminium and copper;  
 Brazing;  
 Sticker removal (at low power).

### Use Not Recommended

Small parts





Heater footprint



60 mm

## PRODUCT COMPATIBILITY

### Powerduction :

39LG	058583 080027	+ Optional 28L adapter (064492) 
50LG	055599	
110LG	058590 065246	With 32L adapter already supplied (064515) 
160LG	057814 065253	
220LG	066861 074576	

### Accessory :

Inductor protection  069701