

How to extract PSA's new anti-theft wheel locking bolts

1. Description of the locking bolt

- Two free turning rings
- Only 4mm space for clamping to the bolt
=> risk of sliding off while unbolting.



2. Extraction

a. Drilling the first ring (use Guide N°3)



b. Drilling of the second ring and extraction.

